


All American pad-transfer printing pads are available in several color-coded durometers. Hundreds of standard as well as custom molds are in stock, and custom pad development is one of our strengths. Our precision molds are produced in a new state-of-the-art laboratory, and all pad compounding is fully automated to insure consistency and repeatability. Molds for more than 1,000 different shapes and sizes are in stock and available for immediate use.

Please be aware it takes 5 - 7 working days to produce these custom pads.

1. Choosing the Size and Shape




Pads come in a variety of shapes and sizes. Some of the standard shapes are represented below. Generally, the pad with the steepest angle, the hardest durometer, and the greatest mass will generate the best print quality. The pad should be at least 20-30% larger than maximum image size required.

Pad recommendations are readily available from our Technical Service Department; send the image size, location, and sample of the substrate.








2. Choosing the Pad Material

All American offers pads made from a variety of materials. You may choose the material that best fits your needs.

Instaprint	Duroflex	Ultraprint	
Available in durometers ranging from 40 to 85.	Available in durometers ranging from 40 to 85.	Available in durometers ranging from 40 to 85.	
off white			
A long-life pad formulated to outperform conventional pads and to print without "break-in" cycling.	A wear resistant pad designed for an abrasive surface.	A chemical resistant pad formulated for use with aggressive solvents.	A premium pad produced in precision molds. Designed for the greatest possible print resolution.

Autoflex
A general purpose pad



3. Choosing the Base Material

Our pads can be mounted on a variety of base surfaces which include phenolic, aluminum, and wood.



Aluminum




























Phenolic



Plywood

Custom Pads listed in the next section.

Custom Pads - A Base

<p align="center">A234</p>  <p align="center">D.9" H1.0</p>	<p align="center">A214</p>  <p align="center">D 1.2" H 1.2"</p>	<p align="center">A1056</p>  <p align="center">D 1.18" H1.3"</p>	<p align="center">A1054</p>  <p align="center">D1.05" H1.05"</p>	<p align="center">A920</p>  <p align="center">D1.25" H1.14"</p>
<p align="center">A1052</p>  <p align="center">D1.55" H1.4"</p>	<p align="center">A1055</p>  <p align="center">D1.63" H1.05"</p>	<p align="center">A30/02R</p>  <p align="center">D1.76" H1.63"</p>	<p align="center">A60/02P</p>  <p align="center">D2.36" H1.93"</p>	<p align="center">A60/01R</p>  <p align="center">D2.66" H1.93"</p>
<p align="center">A30/07P</p>  <p align="center">D3.5" H2.2"</p>	<p align="center">A1058</p>  <p align="center">D1.35" H1.28"</p>	<p align="center">A023</p>  <p align="center">D1.18" H1.67"</p>	<p align="center">A599</p>  <p align="center">L1.15" W1.15" H1.25"</p>	<p align="center">A30/01P</p>  <p align="center">D1.46" H1.47"</p>
<p align="center">A025</p>  <p align="center">D1.6" H1.9"</p>	<p align="center">A30/03</p>  <p align="center">D1.93" H1.7"</p>	<p align="center">A165</p>  <p align="center">D1.87" H2.1"</p>	<p align="center">A694</p>  <p align="center">D2.1" H1.87"</p>	<p align="center">A60/01P</p>  <p align="center">D2.49" H1.19"</p>
<p align="center">A742</p>  <p align="center">L6.89" W2.1" H2.15"</p>	<p align="center">A1000</p>  <p align="center">L7.73" W2.52" H2.67"</p>	<p align="center">A142</p>  <p align="center">L7.45" W2.68" H3.17"</p>	<p align="center">A128</p>  <p align="center">L7.5" W2.38" H3.45"</p>	<p align="center">A540</p>  <p align="center">L7.94" W2.67" H2.55"</p>

Custom Pads - A Base (continued)

<p align="center">A386</p>  <p align="center">L3.96" W1.75" H1.33"</p>	<p align="center">A675</p>  <p align="center">L3.14" W4.1" H1.5"</p>	<p align="center">A536</p>  <p align="center">L4.16" W2.2" H2.13"</p>	<p align="center">A1049</p>  <p align="center">L4.32" W3.12" H1.78"</p>	<p align="center">A347</p>  <p align="center">L6.0" W1.8" H2.07"</p>
<p align="center">A60/03R</p>  <p align="center">D4.1" H3.6"</p>	<p align="center">A478</p>  <p align="center">D4.76" H4.27"</p>	<p align="center">A029</p>  <p align="center">D3.0" H1.7"</p>	<p align="center">A30/06R</p>  <p align="center">D3.12" H1.73"</p>	<p align="center">A1053</p>  <p align="center">L7.38" W3.36" H3.41"</p>
<p align="center">A923</p>  <p align="center">L8.18" W5.4" H2.95"</p>	<p align="center">A304</p>  <p align="center">L7.8" W5.3" H4.65"</p>	<p align="center">A689</p>  <p align="center">D3.97" H2.8"</p>	<p align="center">A930</p>  <p align="center">D4.12" H2.88"</p>	<p align="center">A60/04P</p>  <p align="center">D5.8" H3.88"</p>
<p align="center">A1046</p>  <p align="center">D5.8" H3.6"</p>	<p align="center">A1048</p>  <p align="center">D6.5" H4.45"</p>	<p align="center">A715</p>  <p align="center">L1.66" W.91" H1.25"</p>	<p align="center">A1043</p>  <p align="center">L1.12" W1.12" H1.1"</p>	<p align="center">A836</p>  <p align="center">L1.65" W1.65" H1.5"</p>
<p align="center">A640</p>  <p align="center">L1.6" W1.6" H1.28"</p>	<p align="center">A814</p>  <p align="center">L1.78" W1.5" H1.42"</p>	<p align="center">A841</p>  <p align="center">L2.1" W1.24" H1.52"</p>	<p align="center">A863</p>  <p align="center">L2.88" W1.25" H1.8"</p>	<p align="center">A887</p>  <p align="center">L2.8" W2.24" H1.79"</p>











Custom Pads - A Base (continued)

<p align="center">A1047</p>  <p align="center">L3.14" W2.29" H1.98"</p>	<p align="center">A164</p>  <p align="center">L3.91" W1.6" H1.95"</p>	<p align="center">A067</p>  <p align="center">L3.9" W1.77" H2.03"</p>	<p align="center">A665</p>  <p align="center">L4.03" W2.4" H2.0"</p>	<p align="center">A1045</p>  <p align="center">L2.86" W2.23" H2.03"</p>
<p align="center">A996</p>  <p align="center">L3.38" W2.46" H2.31"</p>	<p align="center">A105</p>  <p align="center">L4.16" W2.81" H1.97"</p>	<p align="center">A295</p>  <p align="center">L3.38" W3.32" H2.96"</p>	<p align="center">A726</p>  <p align="center">L3.38" W3.32" H2.94"</p>	<p align="center">A957</p>  <p align="center">L5.35" W3.53" H3.05"</p>
<p align="center">A136</p>  <p align="center">L4.33" W3.99" H3.09"</p>	<p align="center">A680</p>  <p align="center">L2.7" W1.0" H.95"</p>	<p align="center">A1060</p>  <p align="center">L4.34" W.68" H.86"</p>	<p align="center">A510</p>  <p align="center">L2.35" W1.77" H1.63"</p>	<p align="center">A624</p>  <p align="center">L2.4" W1.85" H1.76"</p>
<p align="center">A747</p>  <p align="center">L10.23" W2.06" H2.1"</p>				









Custom Pads - T Base

<p align="center">T002</p>  <p align="center">D2.1" H1.7"</p>	<p align="center">T027</p>  <p align="center">D3.5" H2.88"</p>	<p align="center">T199</p>  <p align="center">D1.27" H1.27"</p>	<p align="center">T092</p>  <p align="center">D1.27" H1.46"</p>	<p align="center">T600</p>  <p align="center">D1.17" H1.24"</p>
<p align="center">T010</p>  <p align="center">D1.58" H1.5"</p>	<p align="center">T001</p>  <p align="center">D1.56" H1.54"</p>	<p align="center">T010SP</p>  <p align="center">D1.6" H1.7"</p>	<p align="center">T011</p>  <p align="center">D2.03" H2.16"</p>	<p align="center">T050S</p>  <p align="center">D2.22" H1.9"</p>
<p align="center">T050</p>  <p align="center">D2.27" H2.2"</p>	<p align="center">T098</p>  <p align="center">D2.74" H2.64"</p>	<p align="center">T135</p>  <p align="center">L1.88" W1.07" H1.08"</p>	<p align="center">T078</p>  <p align="center">L1.5" W1.2" H1.4"</p>	<p align="center">T084</p>  <p align="center">L.85"" W.85" H.29"</p>
<p align="center">T020</p>  <p align="center">L1.28" W1.98" H1.54"</p>	<p align="center">T136</p>  <p align="center">L2.67" W1.52" H1.62"</p>	<p align="center">T119</p>  <p align="center">L2.62" W1.82" H1.65"</p>	<p align="center">T017</p>  <p align="center">L2.7" W2.1" H2.2"</p>	<p align="center">T022</p>  <p align="center">L2.7" W2.7" H2.2"</p>
<p align="center">T056</p>  <p align="center">L3.19" W1.84" H2.24"</p>	<p align="center">T166</p>  <p align="center">L3.57" W2.7" H2.29"</p>	<p align="center">T185</p>  <p align="center">L4.38" W2.53" H2.01"</p>	<p align="center">T019</p>  <p align="center">L1.45" W.795" H1.15"</p>	<p align="center">T212</p>  <p align="center">L1.78" W.695" H.7"</p>





Custom Pads - T Base (continued)

<p align="center">T070</p>  <p align="center">L2.72" W.96" H.89"</p>	<p align="center">T049</p>  <p align="center">L2.5" W1.00" H1.00"</p>	<p align="center">T087</p>  <p align="center">L3.54" W1.18" H1.08"</p>	<p align="center">T138</p>  <p align="center">L4.4" W1.1" H1.16"</p>	<p align="center">T069</p>  <p align="center">L8.2" W.61" H.68"</p>
<p align="center">T088</p>  <p align="center">L11.0" W1.1" H1.14"</p>	<p align="center">T091</p>  <p align="center">L3.25" W1.72" H1.76"</p>	<p align="center">T030</p>  <p align="center">L4.69" W1.99" H2.3"</p>	<p align="center">T029</p>  <p align="center">L4.75" W2.85" H2.35"</p>	<p align="center">T024</p>  <p align="center">L4.6" W2.6" H2.35"</p>







Custom Pads - M Base

<p align="center">M30/01P</p>  <p align="center">L2.85" W1.53" H1.72"</p>	<p align="center">M30/03P</p>  <p align="center">L2.9" W1.93" H1.96"</p>	<p align="center">M30/02P</p>  <p align="center">L2.85" W1.7" H1.86"</p>	<p align="center">M30/04P</p>  <p align="center">L3.09" W1.62" H1.63"</p>
<p align="center">M30/02R</p>  <p align="center">L2.89" W1.8" H1.8"</p>	<p align="center">M30/03R</p>  <p align="center">L2.89" W1.96" H1.72"</p>	<p align="center">M30/05P</p>  <p align="center">L4.02" W1.66" H2.02"</p>	<p align="center">M60/01P</p>  <p align="center">L3.94" W2.6" H2.07"</p>

Custom Pads - M Base (continued)

<p>M30/14</p>  <p>L6.03" W2.4" H2.82"</p>	<p>M60/01R</p>  <p>L3.91" W2.80" H2.05"</p>	<p>M30/12</p>  <p>L4.08" W3.58" H2.09"</p>	<p>M60/02P</p>  <p>L4.97" W3.99" H2.67"</p>
---	---	---	---

Custom Pads P/CB Base

<p>P128</p>  <p>0.5" H.63"</p>	<p>P135</p>  <p>D.675" H.63"</p>	<p>P193</p>  <p>L1.22" W.69" H.67"</p>
<p>CB/04</p>  <p>L3.65" W2.8" H2.18"</p>	<p>CB/01</p>  <p>L3.52" W2.12" H1.5"</p>	<p>CB/06</p>  <p>L5.05" W3.35" H2.1"</p>

For questions or ordering, please call 215-634-2235
Monday through Friday 8:30 a.m. to 6:00 p.m. Eastern Standard Time

All American
Manufacturing and Print Supply Co.

495 East Erie Avenue
Philadelphia, PA 19134